


Installation of equipment

IMPORTANT: It is essential to refer to the installation instructions for information on the size of the safety areas.

———— Impact area (minimum normative surface)

- - - - - Free space



1	0,6m	22m ²



2



05h30



0.2m³



22m²



142kg



24kg

EN

1176