


Play value :



2



Q

_ _ _



Installation of equipment

IMPORTANT: It is essential to refer to the installation instructions for information on the size of the safety areas.


Impact area (minimum normative surface)

Free space






Zone d'Inpact Sol souple Inpact Area Wetpour Area de Inpacto Fallraun bei synthetischen Fallschutz



Point de Référence Setting Dut Point Punto de referencio Bezugspunkt Zone d'Inpoct Sol fluent Inpoct Area Loose particle naterial Arenero Fallraun bei Iosen Bodennaterial



Point de Référence Setting Dut Point Punto de referencia Bezugspunkt

	Å Ti	
1	1,20m	19m²
2	1,20m	22m²

~

